



BATTERIES

<u>PORTABLE BATTERY MOD. 1535 / 1537</u>	<u>DELL</u>
<u>PORTABLE BATTERY MOD. G460 6 CELL</u>	<u>LENOVO</u>
<u>BATTERY MOD CQ42 FOR DM4-DV3-DV5-DV6-DV7 6CELL</u>	<u>HP</u>
<u>BATTERY MOD DV2000 FOR DV6000 V3000 V6000 6CELL</u>	<u>HP</u>
<u>BATTERY MOD DV4 FOR DV5-DV6-G60-G50-CQ40-HD 6CELL</u>	<u>HP</u>
<u>BATTERY MOD VGP-BPS26 SERIES C-CA-CB 6CELL</u>	<u>SONY</u>
<u>BATTERY MOD. 4310 4520 4720</u>	<u>ACER</u>
<u>BATTERY MOD. 4320 / 4321 06 CELLS</u>	<u>HP</u>
<u>BATTERY MOD. 4530 4430S 6 CELLS</u>	<u>HP</u>
<u>BATTERY MOD. DV4-5000 6 CELLS</u>	<u>HP</u>
<u>BATTERY MOD. G400S 6 CELLS</u>	<u>LENOVO</u>
<u>BATTERY MOD. HS04 04 CELLS</u>	<u>HP</u>
<u>BATTERY MOD. JC04, JC03, 240 G6, 245 G6</u>	<u>HP</u>
<u>BATTERY MOD. KIO4 04 CELLS</u>	<u>HP</u>
<u>BATTERY MOD. M4400 B50-70</u>	<u>LENOVO</u>
<u>BATTERY MOD. MR90Y, N121Y, G35K4 6 CELLS</u>	<u>DELL</u>
<u>BATTERY MOD. N3421 3521 XCMRD</u>	<u>DELL</u>
<u>BATTERY MOD. OA04 14.8V /2200mAh</u>	<u>HP</u>
<u>BATTERY MOD. PA3817 / PA3819 10.8V. 4400mAh</u>	<u>TOSHIBA</u>



BOETEC
VINTAGE SERIES

BATTERY MOD. PA5107 L45 L55 INTERNAL 14.4V 43WH 2838mAh 06C	TOSHIBA
BATTERY MOD. PA5185 14.8V 2200	TOSHIBA
BATTERY MOD. PI06 10.8V 4400 mAh	HP
BATTERY MOD. PROBOOK 430 G1 RA04	HP
BATTERY MOD. PROBOOK 430 G3 440 G3 RO04	HP
BATTERY MOD. Q308-R470-R458-R460 06 CELLS	SAMSUNG
BATTERY MOD. VI04 14.4V/2200mAh 04 CELLS	HP
BATTERY MOD. X455 (C21N1401) A455L	ASUS
